



## CS200 Series Door Template Index

### Door Templates

Function	Faceplate	Door Edge		Door Thickness	Wood or Composite	Metal
		Flat	Bevel			
CS210	1" (25mm)			1-3/4" - 2" (44mm-51mm)		
	Square corner, standard	X	X		<a href="#">CS101</a>	<a href="#">CS103</a>
	1/4" radius corner	X	X		<a href="#">CS102</a>	

\* Strike also shown on template

### Strike Templates

Number	Description	Template Number	
		Wood	Metal
10-109			
10-121	10-094 x 10-026 combination	<a href="#">J933</a>	<a href="#">J937</a>
10-122	10-116 x 10-027 combination	<a href="#">J934</a>	
10-123	10-092 x 10-027 combination	<a href="#">J935</a>	<a href="#">J938</a>
10-124, 10-259	10-095 x 10-026 combination	<a href="#">J936</a>	
10-094	Deadbolt, square corner, no box	<a href="#">J884</a>	<a href="#">J477</a>
10-116			
10-092	Deadbolt, full lip, round corner, 1/4" (6mm) radius, no box	<a href="#">J786</a>	
10-095	Deadbolt, full lip, square corner, no box	<a href="#">J787</a>	
10-001	T-strike, square corner, box	<a href="#">J928</a>	<a href="#">J929</a>
10-026	Full lip, square corner, no box	<a href="#">J458</a>	<a href="#">J459</a>
10-027	Full lip, round corner, 1/4" (6mm) radius, no box	<a href="#">J460</a>	<a href="#">J461</a>