



INSTALLATION INSTRUCTIONS

- PREPARE INSIDE FACE OF DOOR FOR DEVICE.
 - SEE DEVICE DIRECTIONS FOR LOCATIONS OF VERT. AND DEVICE REF. CENTERLINES.
- PREPARE OUTSIDE FACE OF DOOR FOR TRIM.
 - TRANSFER VERT. AND DEVICE REF. CENTERLINES FROM INSIDE FACE TO OUTSIDE FACE OF DOOR. BE SURE VERT. CENTERLINE IS PARALLEL TO EDGE OF DOOR.
 - LOCATE AND PREPARE ALL HOLES AS INDICATED.
- INSTALL TRIM AND CYLINDER (IF REQUIRED).

NOTE: FOR TRIDENT TRIM, PERFORM STEPS A, E & F ONLY.

 - INSTALL CYLINDER (IF REQUIRED) TO TRIM USING CYLINDER ANCHOR (SEE LOWER LEFT).
 - ASSEMBLE PULL GRIP (IF REQUIRED) TO TRIM PLATE USING HEX STUD.
 - INSERT SEXBOLT(S) AND APPLY TRIM TO DOOR.
 - MOUNT BOTTOM PULL USING 1/4"-20x2-1/4" FPHMS.
 - TOP TWO MOUNTING STUDS ARE THRU-BOLTED TO DEVICE WHEN DEVICE IS INSTALLED.
 - CUT CYLINDER TAILPIECE TO EXTEND 1/8" TO 3/16" BEYOND INSIDE FACE OF DOOR.
- INSTALL DEVICE ON DOOR PER DEVICE INSTRUCTIONS.

