



**SECURED SIDE:**  
Isolate and insulate  
wires not used

**UN-SECURED SIDE:**  
Isolate and insulate  
wires not used

Remove factory jumper wire  
from V+ to COM!

**WARNING:**  
You must check with your local AHJ  
If this is going to control an  
emergency egress door. Delayed  
egress hardware may be required in  
direction of egress

PowerNet RC Jumper Positions		RC-03.EDK.Mag.ExitButton.FA Relay.DSM. Read IN-Read OUT	
		Dwg No:	Sheet 1 of 1
Date: 4-13-18	Drawn By: David Tamarchenko	Version: 1.00.00	
		<b>ISONAS</b> PURE IP ACCESS CONTROL 4750 Walnut Street Suite 110 Boulder, CO 80301 www.isonas.com	