



95" [2413]

Hole Preparation

3/8" Drill thru:
12 places

Metal frame:
Standard self drilling
self tapping screws -
No drilling required
Optional thread forming screws -
#13 or 3/16" drill

Wood frame:
5/32" drill, 1.5" deep
22 places

Optional:
#12 Pan head,
self drilling
screws, 4 places

Vertical distance between holes		
	Inch	mm
A	1.5"	38.1
B	3"	76.2
C	2.5"	63.5
D	10"	254
E	5"	127

Notes
<p>Note: Total Door Undersizing Single Square Edge Door – 5/16" Single Bevel Edge Door – 11/32" Pair of Doors, each leaf, Square Edge Door – 9/32" Pair of Doors, each leaf, Bevel Edge Door – 5/16" Reinforcement recommended for six hole patterns at top and bottom of frame leaf, and four hole patterns at top and bottom of door leaf.</p>

IVES 046HD 95" Half Surface Continuous Hinge Profile Template

ALLEGION © 2015 Allegion 829689-00 Rev. 04/15-d

Note: Dimensions in [] are millimeters

Template Number **829689-00(D)**