



Total Door Undersizing

- Single Square Edge Door - 15/32"
- Single Bevel Edge Door - 1/2"
- Pair of Doors, each leaf, Square Edge Door - 7/16"
- Pair of Doors, each leaf, Bevel Edge Door - 15/32"

See installation instructions for reinforcement requirements.

Hole Preparation

Metal Frame:
 #12-24 x 3/4" self-drilling tapping screws
 #16 pilot drill is recommended for all holes

Wood Frame:
 1/8" pilot drill

Vertical distance between holes

	A	B	C	D
Inch	1.50"	2.50"	3"	10"
mm	38.1	63.5	76.2	254.0



114XY 83" & 85" FULL MORTISE, CONCEALED NARROW FRAME WITH EDGE PROTECTOR CONTINUOUS HINGE TEMPLATE



NOTE: DIMENSIONS IN () ARE IN MILLIMETERS

TEMPLATE NUMBER: 829704(B)

Date: 10-16-15