



Total Door Undersizing

Single Square Edge Door - 15/32"
 Single Bevel Edge Door - 1/2"
 Pair of Doors, each leaf, Square Edge Door - 7/16"
 Pair of Doors, each leaf, Bevel Edge Door - 15/32"

See installation instructions for reinforcement requirements.

Hole Preparation

Metal Frame:
 #12-24 x 3/4" self-drilling tapping screws
 #16 pilot drill is recommended for all holes

Wood Frame:
 1/8" pilot drill

Vertical distance between holes

	A	B	C	D	E	F	G
Inch	1.50"	2.50"	3.00"	3.50"	5.00"	5.50"	10.00"
mm	38.1	63.5	76.2	88.9	127	139.7	254



045XY 119" HALF SURFACE
 NARROW FRAME
 CONTINUOUS HINGE TEMPLATE



NOTE: DIMENSIONS IN () ARE IN MILLIMETERS

TEMPLATE NUMBER: 829727(A)

Date: 5-20-15