



**Total Door Undersizing**

- Single Square Edge Door - 15/32"
  - Single Bevel Edge Door - 1/2"
  - Pair of Doors, each leaf, Square Edge Door - 7/16"
  - Pair of Doors, each leaf, Bevel Edge Door - 15/32"
- See installation instructions for reinforcement requirements.

**Hole Preparation**

- Metal Frame:**  
#12-24 x 3/4" self-drilling tapping screws  
#16 pilot drill is recommended for all holes
- Wood Frame:**  
1/8" pilot drill

**Vertical distance between holes**

	A	B	C	D	E	F	G
Inch	1.50"	2.50"	3.00"	3.50"	5.00"	5.50"	10.00"
mm	38.1	63.5	76.2	88.9	127	139.7	254