



**Total Door Undersizing**

- Single Square Edge Door - 15/32"
  - Single Bevel Edge Door - 1/2"
  - Pair of Doors, each leaf, Square Edge Door - 7/16"
  - Pair of Doors, each leaf, Bevel Edge Door - 15/32"
- See installation instructions for reinforcement requirements.

**Hole Preparation**

- Metal Frame:**  
 #12-24 x 3/4" self-drilling tapping screws  
 #16 pilot drill is recommended for all holes
- Wood Frame:**  
 1/8" pilot drill

**Vertical distance between holes**

	A	B	C	D
<b>Inch</b>	1.50"	2.50"	3"	10"
<b>mm</b>	38.1	63.5	76.2	254.0



224XY 119" FULL MORTISE  
 WITH EDGE PROTECTOR  
 CONTINUOUS HINGE PROFILE TEMPLATE



NOTE: DIMENSIONS IN ( ) ARE IN MILLIMETERS

TEMPLATE NUMBER: 829747(A)

Date: 5-20-15