



INSTRUCTIONS:

1. PLACE FLOOR STOP IN DESIRED LOCATION AND MARK HOLES.
2. PREPARE MOUNTING HOLES
3. INSTALL FLOOR STOP WITH APPROPRIATE SCREWS.

SCREW DETAILS

FS441-MS	1	5/16-18 X 2" STUD W/ EXPANSION SHIELD
FS442-MS	1	1/4-20 X 1" FPHMS
	1	1/4-20 TAMPIN
FS441-WS	1	5/16-18 X 2 1/2" HANGER BOLT
FS442-WS	1	#14 X 1 1/4" OPHWS

IVES

**FS441 & FS442 FLOOR STOP
INSTALLATION TEMPLATE**

IR Security & Safety®

NOTE: DIMENSIONS IN () ARE MILLIMETERS.

TEMPLATE NUMBER: INST.FS441-442_0

DATE: 07/26/01