



INSTRUCTIONS:

1. OPEN DOOR TO DESIRED POSITION.
2. PLACE STRIKE AND HOLDER AS ILLUSTRATED.
3. LOCATE THE MOUNTING HOLES.
4. PREPARE MOUNTING HOLES AS NECESSARY.
5. INSTALL BODY AND STRIKE.

NOTES:

1. DOORS SHOULD BE PROPERLY REINFORCED WITH $\frac{3}{16}$ " (5) MINIMUM THICKNESS PLATE.

	QTY	SCREW DETAILS
STRIKE	2	#8 X 1" FPHSMS
FS451-MS BODY	1	$\frac{5}{16}$ -18 X 2" THREADED STUD
	1	LEAD SHIELD
	1	$\frac{1}{4}$ -20 X 1" FPHMS
FS451-WS BODY	1	$\frac{1}{4}$ -20 TAMPIN
	1	$\frac{5}{16}$ -18 HANGER BOLT
	1	#14 X 1 1/4" OPHWS



FS451 MANUAL FLOOR HOLDER
INSTALLATION TEMPLATE



NOTE: DIMENSIONS IN () ARE MILLIMETERS.

TEMPLATE NUMBER: INST.FS451_0

DATE: 09/01/01