



INSTRUCTIONS:

1. PLACE BUMPER ON WALL AND LOCITE THE MOUNTING HOLE.
2. DRILL A $\frac{1}{4}$ " (6) DIAMETER HOLE.
3. INSERT PLASTIC ANCHOR IN HOLE.
4. HAMMER PIN IN.
5. SCREW BODY WITH RUBBER ON TO BACK PLATE.

QTY	SCREW DETAILS
1	#10 X 1" FPHSMS
1	#10 PLASTIC ANCHOR

IVES

WS404 WALL BUMPER INSTRUCTION

ALLEGION

NOTE: DIMENSIONS IN () ARE IN MILLIMETERS

TEMPLATE
NUMBER:

INST.WS404_B

DATE:
05-29-15