

Ives Floor Stops, Wall Stops, Bumpers and Silencers Template Index

Floor stops templates

Function	Template Number
436 x 435A combo heights	2234
FS9 semi-automatic floor holder	INST.FS9
FS18S floor stop	INST.FS18S
FS40, FS42 and FS43 automatic door holder	INST.FS40-43
FS434 door stop	INST.FS434
FS436 and FS438 dome stop with FS435 and FS437 risers	INST.FS435-438
FS441 and FS442 floor stop	INST.FS441-442
FS444 and FS448 floor stop	INST.FS444-448
FS446 and FS450 manual floor holder	INST.FS446-450
FS451 manual floor holder	INST.FS451
FS452 kick down holder	INST.FS452
FS455 kick down holder	INST.FS455
FS496 and FS497 automatic floor holder	INST.FS496-497
FS544 and FS555 kick down holder	INST.FS544-555

Bumpers templates

Function	Template Number
408 1/2 wall bumper	2237
408 wall bumper	2238
409 1/2 wall bumper	2236
RB470, RB471 and RB472 roller bumper	INST.RB
WS401 and WS402 wall bumper	610

Silencers templates

Function	Template Number
SR64 and SR65 door silencer	INST.SR

Wall stops templates

Function	Template Number
48B mortise door bolt	223
64 door stop	190
FS18L wall stop	INST.FS18L
FS495 automatic wall holder	INST.FS495
FS1153 and FS1154 plunger door holder	INST.FS1153-1154
WS11 and WS11X wall stop	INST.WS11
WS20 and WS20X manual wall holder	INST.WS20
WS33 and WS33X wall stop	INST.WS33
WS40 wall holder	INST.WS40
WS45 and WS45X automatic wall holder	INST.WS45
WS65 wall door stop	INST.WS65
WS401CCV, WS401CVX, WS402CCV and WS402CVX wall door stop	INST.WS401-402
WS404 wall door stop	INST.WS404
WS406CCV, WS406CVX, WS407CCV and WS407CVX wall door stop	INST.WS406-407
WS443 and WS447 wall door stop	INST.WS443-447
WS445 and WS449 manual wall holder	INST.WS445-449