


**UTILITY HOOK**

FOR USE IN CLOSETS, KITCHENS, BATHROOMS, GARAGES AND BASEMENTS. PROVIDES EASY HANGING FOR CLOTHES, TOOLS, SPORTS GEAR AND MISCELLANEOUS HOUSEWARES.

**INSTALLATION INSTRUCTIONS**

TOOLS REQUIRED: Phillips screwdriver, awl or pencil.

1. Place in desired position and mark.
2. Secure with screws provided.



ASK FOR OTHER FINE HARDWARE BY H.B. IVES




WINDOW LOCKS



DOOR STOPS



COAT & HAT HOOKS



DOOR BOLTS



UTILITY HOOK C576A3 BRASS