TO CONVERT EXISTING DEVICE TO A CYLINDER DOGGING DEVICE

1. Remove device from door.
2. Remove channel cover from device.
3. Remove existing mechanism in channel (i.e. Hex Dogging Unit, Exit Alarm, AE Retrofit Kit, etc.) If appropriate.
4. Slide cylinder dogging sub-assembly and install with device channel using #8-32 x 3/8" UFPHMS screw (see figure 1).
ⓘ **Please note that it is easier to install cylinder dogging sub-assembly in the un-dogged position.**
5. Proceed to cylinder & channel cover installation.

#8-32x3/8" UFPHMS

CHANNEL

FIGURE 1

CYLINDER DOGGING
SUB-ASSEMBLY

CYLINDER AND CHANNEL COVER INSTALLATION

1. Assemble cylinder to cylinder dogging channel cover using cylinder bracket, cylinder nut and cylinder collar (2 required for 1-1/4" long mortise cylinders, 1 required for 1-1/8" long mortise cylinders). Keyway should be oriented as shown (see Figure 2).
ⓘ **Please note: it is no longer required to invert the mortise cam for monarch cylinder dogging!**
2. Slide cylinder dogging channel cover with cylinder into device channel.
3. Proceed with device installation.
4. Check for smooth dogging function after installation of channel end cap.

CYLINDER NUT

CYLINDER RETAINER
BRACKET

CYLINDER DOGGING
CHANNEL COVER

1/8" CYLINDER COLLAR
(2 FOR 1-1/4" LONG
CYLINDER, 1 FOR 1-1/8"
LONG CYLINDER)

MORTISE
CYLINDER

FIGURE 2

Customer Service

1-877-671-7011   www.allegion.com/us

ALLEGION

© Allegion 2014
Printed in U.S.A.
D-4080 Rev. 06/14-b